

1 1/2 Ft to Side of Cone

Drive past the stall the back of the trailer will be at the cone or a little past. Stop

Turn the wheel clockwise (right) <sup>Full</sup> all the way. Back until the landing gear is past the drive tire about a foot. Stop. (Driver side)

Turn the wheel counter clockwise (left) <sup>Full</sup> all the way. Ease around until the tractor and trailer are straight. Look for the target cone on outside of the parking stall. Line up with the center cone. Stop. (Passenger side)

Straighten wheels (2 rounds to the right) back straight and keep the target cone on the outside of the frame until the mirror is at the end of the stall. Stop. (Passenger side)

Counter clockwise (left) <sup>Full</sup> all the way, back until landing gear is visible in the passenger mirror with a foot gap between the landing gear and the drive tire. Stop.

Turn the wheel clockwise <sup>Full</sup> all the way back until the front is all the way in.

NOTE:

In the new truck it will be two landing gears in the mirror.